


现象

- 在安装了 Hypervisor 系统上，安装 Docker 后，运行会报出如下报错



原因

- Hypervisor 占用了虚拟化技术端口，因此使用此项技术的功能都无法使用，例如 VMWare, VirtualBox, Docker。

Automation Help 4.12 说明不支持

- GUID: 9cab0273-63dc-448f-ba19-8d69720f1960
- 路径: Real-time operating system - Target systems - Target systems SG 4 - B&R Hypervisor - Features - Virtualization

Virtualization in the GPOS

It is not possible to use virtualization that uses hardware virtualization functions (e.g. Hyper-V) since B&R Hypervisor exclusively requires these hardware functions.